



Cut away the top of the wall of the catch basins on the intake side to provide a water way 3" deep under the frame, and slope the gutter back for a distance of 2' from the catch basin.

MICROFILMED

FEB 11 1960

INDEXED

DRAWN BY H.W.J.

CHECKED BY H.W.J.

FIELD BOOKS

George Connell
CITY ENGINEER
J.M. Delwood
MGR. OF OPERATION

CITY OF SAN DIEGO--OPERATING DEPARTMENT

DRAINAGE

AT INTERSECTION OF ARCTIC AND B STREETS

Kethner

DATE Jan. 1916

1" = 50'

SCALE 1" = 1'

DRAWING NUMBER

72

B